








Sotka TV-taso 180




1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
x1	x1	x1	x1	x1	x1	x1	x2	x1	x2	x2	x1	x1	x1	x1	x1	x2	x1




A	8x30	B	Ø7x45	C	Ø15x11	D	Ø12x11	E	3,5x35	K	Ø5,8x8	L	M4x22	M	M4x10	I	1,2x20
	x24		x28		x26		x2		x4		x4		x6		x2		x50
O	192mm	P	27x374	R	Ø17	S	Ø26	T	15x24x9	U	2 mm	V	Ø5x16	W	Ø7x50	X	4 mm
	x3		x2		x12		x4		x2		x4		x8		x6		x1
Y	3,5x15																
	x12																




3




4




5




6



7




8




6


9



10



11



12

